



MAD DOGG ATHLETICS, INC.

2111 Narcissus Court • Venice, CA 90291 • USA

TEL 800 847 SPIN (7746) or 310 823 7008 **FAX** 310 823 7408

MAD DOGG ATHLETICS EUROPE, BV

Scheldeweg 3 • 3144 ES Maassluis • The Netherlands

TEL +31 (0) 10 590 4508 • **FAX** +31 (0) 10 590 0054

Safety Precautions

Install tablet mount securely. Do not adjust tablet or tablet mount while pedaling. Remove tablet before moving your indoor cycle and do not place direct force on tablet mount. Mad Dogg Athletics, Inc. is not responsible for any injuries or damages caused to any person or item during the installation or use of this tablet mount.

© 2017 Mad Dogg Athletics, Inc. All rights reserved. SPIN®, Spinning®, Spinner® and the Spinning logo are registered trademarks of Mad Dogg Athletics, Inc.

STANDARD TABLET MOUNT item # 7455REV1

Please read instructions carefully before use.



Package Contents:




GN086-12-SBH
Heavy-Duty
Adjustable C-Clamp
Mount with 12"
Flexible Gooseneck




TAB00
Slim-Grip® Universal 1
Tablet Holder


- 1. Place the Mount**
Open the C-clamp on the bottom of the mount by turning the clamp knob counter clockwise. Tighten the clamp knob to secure on mounting area.



- 2. Attach the Holder**
Attach a holder to the C-clamp mount by inserting the Dual-T tabs into the holder and sliding the holder down to lock.



- 3. Mount a Tablet**
Insert tablet into holder by pushing down the bottom spring-loaded support legs with the tablet. Slide the top of the tablet under the top support legs until it fits snugly in the holder.



- 4. Adjust the Mount**
Adjust the position of the mount by firmly bending the neck. Ball head can also be adjusted via the tightening ring.

